

# GPS DATA LOGGER

## Quick Start Guide



DG-200

## Accessories



DG-200 Unit



CD




Quick Guide



USB Cable

Optional:



AC Charger



Hang Tape

Note:  
If any item is missing or damaged, please contact with your local retailer.

## Appearance

**Memory LED** Blue

**Power LED** Red / orange

**Power/ Save button**

**GPS LED** Green

**Mini USB Charging / transmitting**



## Start to Use

### DG-200 Operation

1. Press and hold the power button for three seconds to turn on DG-200. Then you would see GPS LED on.
2. After getting GPS fix and starting to record traveled path, GPS LED would flash.
3. When DG-200 could get GPS fix, you could short click power button to save the present location to inner memory flash. You could see memory LED flash once to show the present location is saved. (You could not save location if it could not get GPS fix.



DG-200 Power Button



LED status after turning on device

### DG-200 Power Off

Under power-on status, press and hold power button for three seconds to turn off device. GPS LED would be off after device is powered off.

### DG-200 Connection with PC

1. Connect DG-200 and PC by USB cable.
2. Turn on DG-200 PC Utility.
3. Run "PC Utility" program and you could use the functions of the program.



USB Cable connection

## DG-200 PC Utility Operation



**1 Menu bar:** File View Setup Device Help

**2 Tool bar:** [Icons]

**3 Traveled path data list:**

List the traveled path data loaded from DG-200 or from file

**4 Traveled path information field:**

Show the information of traveled data, including date, time, longitude, latitude, speed, and height (according to the DG-200 data setting)

**5 Google Map Display:**

Show the selected point of the traveled data list on Google Map